



SAMMITR

Date...../...../.....

Version 1.0



SAMMITR

Mechanical Installation Manual


for

Mitsubishi triton
2023






SAMMITR






SAMMITR


■ Steel Canopy S-Plus V2




Glass Slide Window




Solid Window



Solid Birdwing Window (Handle Lock)




Glass Birdwing Window (Handle Lock)




Glass Birdwing Window (Electric Lock)


■ Steel Canopy SUV-Plus V4




Glass Slide Window



Glass Fix Window




Glass Birdwing Window (Electric Lock)




Glass Birdwing Window (Handle Lock)


■ Steel Canopy TL-1



Glass Slide Window



Glass Birdwing Window (Handle Lock)



Glass Birdwing Window (Electric Lock)




Mechanical Installation Manual

All Models

Steel Canopy : TL-1
Version 1.0



Part In Main Carton

P1: Steel Canopy TL-1



Kit Box


Part List Paper




K1 : C-Clamp



K8 : T Paint



K3 : Wiring No.38




T6 : Hexalobular Wrench # T40


Require Tools



T1 : 13 mm. Wrench




T3 : 10,12mm. Torque Wrench



T7 : Measuring Tape/Ruler




T2 : 10 mm. Wrench



T4 : Tape



T5 : Electric Tape




T8 : Fabric





1

The Procedure of checking the Sammitr canopy box before installation.



Brand
Model
Type
Year
Color
Part number
Serial number

1. Make sure that Sammitr canopy box is in good condition, No marks, distorts or any damages.
2. Check Model / Year of the canopy and Model / Year of the vehicle which have to be matching.
3. Check canopy serial number / model code and vehicle serial number / model code which have to be matching by looking at the rear canopy handle.
4. Check all the accessories received inside the box with the Packing List.






2


The preparation process of Sammitr Canopy TL-1 model before installation with the vehicle.

1




1. Canopy have to be in good condition, no damage, dent, cracks, smooth surface including no window damages or cracks.
2. Locking system is working for both keys.
3. Canopy sides are not damage, dent or cracks.
4. Canopy front window panel is working (open/close), no cracks or damages occurrences.
5. Check the Rear Door by open and close.


2




4



3



5







SAMMITR

3


Tape Glue




2



Pull tape glue out 10 cm. on each side.



Alignment the position between the edge of tailgate and Frame Weather Strip.




Self-tapping screw

Pull the tape glue.




4

**The process of preparing Sammitr Canopy
TL-1 model before install on the vehicle.**




5



The process of lifting the canopy onto the vehicle tub by using 4 people for lifting.




6




Lift canopy over the pick up truck by rising the rear part higher and the front part to be in the parallel with the edge of the vehicle tub.

7



8




After get the distance in front part and then put the rear part to cover the vehicle tub.

Make sure the distance between canopy edge and vehicle rear tub are equivalent both left and right sides.




9




Side edge of canopy to be in the parallel with the Side edge of the vehicle tub.



10




11




After finished measure the side part, check the distance at rear part of canopy which must have to be in the parallel with the Rear edge of the vehicle tub.





Steps of canopy C-Clamp bolts tightening onto vehicle.




Steps of canopy C-Clamp bolts tightening onto vehicle.





16


The process of C-Clamp installation TL-1 canopy model with the vehicle.



17

Open / take off the rubber plug.








19

Tighten bolts of c-clamp by using pound wrench, with the pressure of 16 Nm.



T3

D-Cab

Tighten canopy C-Clamp bolts with vehicle all 4 positons.

20

Caution : Before tighten bolts position 3 and 4 please make sure that the distance between the rear left and right pole of the canopy is equal.


D-Cab

Steps of canopy C-Clamp bolts tightening onto vehicle.



21

Tighten bolts of c-clamp by using pound wrench, with the pressure of 16 Nm.




T3

C-Cab

Tighten canopy C-Clamp bolts with vehicle all 6 positons.



22




Caution : Before tighten bolts position 5 and 6 please make sure that the distance between the rear left and right pole of the canopy is equal.

C-Cab

Steps of canopy C-Clamp bolts tightening onto vehicle.










SAMMITR

27



Close the rubber plug.

28



The process of canopy installation is completed.




SAMMITR

Electrical Installation




SAMMITR

29






29



Take off the Wiring Cover at the driver side in order to check the wiring position.

30




Socket light

Socket right




31




Harness Central Lock No.38





32




Harness Central Lock No.38




Take off the Wiring Cover at the driver side in order to check the wiring position.




Control Box position that will connect with Harness Central Lock No.38



Step of checking Switch on position, begin with turning the key to ON position.




Checking the Switch On of vehicle position by using the Test Lamp kit.



Connect the Harness Central Lock No.38 with the vehicle socket by bring the Red Wiring (Switch ON) of the Harness Central Lock No.38 connects with the purple wiring (Switch ON) of the vehicle wiring.




38



LOCK

Step of Checking the light of the Central Lock (Lock), begin with push the Lock button at the door panel.

39




Socket right


LOCK (Car)
(black)

LIGHT ON

Checking the light of the Central Lock (Lock) of vehicle position by using the Test Lamp kit.




Connects the Blue Wiring (Central Lock/Lock Switch) of the Harness Central Lock No.38 with the Black wiring (BK) of the vehicle (Lock Signal)



Step of Checking the light of the Central Lock (UnLock), begin with push the UnLock button at the door panel.




42



Checking the light of the Central Lock (Lock) of vehicle position by using the Test Lamp kit.


43



Connects the Green Wiring (Central Lock/Unlock Switch) of the Harness Central Lock No.38 with the White Wiring (WH) of the vehicle (Unlock Signal).




44



Checking the Battery (12V) light of the vehicle position by using the Test Lamp kit.


45



Connects the Red Wiring Defogger (20A) and Red Wiring Room Lamp (5A) of the Harness Central Lock No.38 with the Red Wiring Battery (12V) of the vehicle as shown in picture.





46




Connecting the Black Wiring (Ground) at the vehicle structure positon of the Harness Central Lock No.38.



47



Connects the Black Wiring (GROUND) of the Harness Central Lock No.38 with the vehicle structure, tighten the




Assemble the Switch Cover with the Harness Central Lock No.38 Wiring Switch.



Connects between the 1 wiring and the 2 wiring.



50



Take off the Wiring Cover at the driver side in order to check the wiring position.


51



Running canopy wiring via vehicle wiring hole/pipe along under the chassis.




52




Remove the cover under the console.

53






54



Run the Harness Central Lock No.38 wiring at passenger position


55



The Step of Harness Central Lock No.38 wiring running picture




56



the wiring hole process.

57



Silicone seal the wiring hole process.



58 The Step of wiring running diagram


Point 1 Wiring running from driver side through passenger side.

Point 2 Running canopy wiring via vehicle
wiring hole/pipe along under the chassis.


Point 3 Wiring that run under vehicle
along the chassis.

Point 4 Wiring that run via
chassis at the fender area.

Point 5 Wiring that running
up the rear light in order to
connect with the other wiring set.




59



Take off the Rear Light by using wrench No.10




60



Take off the Rear Light vehicle.

61




Take off the Rear Light vehicle.




62

Point 5 Wiring that running up the rear light in order to connect with the other wiring set.



Running the Harness Central Lock No.38 up to the vehicle rear light in order to connects with the Harness Central Lock No.40.


63



Run the rod along the vehicle edge till the Rear vehicle light.




64



Running the Harness Central Lock No.40 along the vehicle tube through the rear light.


65



The Harness Central Lock No.40 wiring vehicle position and the Harness Central Lock No.38 wiring set.

66


Central Lock
Wire Connect




The process of connecting the Central Lock (BL,DG) wiring of the Harness Central Lock No.40 with the Central Lock (BL,DG) wiring of the Harness Central Lock No.38.

67

Room Lamp
Wire Connect




The process of connecting the Room Lamp (RD,BK) wiring of the Harness Central Lock No.40 with the Room Lamp (RD,BK) wiring of the Harness Central Lock No.38.




The step of connecting the Defogger (YL/RD) wiring of the Harness Central Lock No.38 with the Defogger (YL/RD) wiring of the Harness Central Lock No.38.

The position of connecting the Red and Black Wiring of the Third Brake Light (RD,BK) circuit of the Harness Central Lock No.38 with the vehicle rear light.




Third Brake Wiring (Short wire, Red wire) of the Harness Central Lock No.40 and Brake Light (Long wire, Red wire) of the Harness Central Lock No.40




Bring the red wiring, Third Brake Light (Short wire) of the Harness Central Lock No.40 connecting with Brake Light (Long wire) of the Harness Central Lock No.40.


After finish the installation step no.37 Bring the Red Wiring, Brake wiring (Long wire) of the Harness Central Lock No.40 connecting with the wiring (Green/White wire) of the vehicle.




Bring the blue wiring, Dimlight of the Harness Central Lock No.40 connecting with Dimlight of the vehicle (green wiring).



Bring the yellow Wiring, Turn light wiring (YL) of the Harness Central Lock No.40 connecting with Turn Light wiring of the vehicle green/yellow wire (GN/YL).




Bring the Black Wiring, GROUND (Short wire) and GROUND (Long wire) of the Harness Central Lock No.40 connecting with the White/Black (WH/BK) Ground wiring of the vehicle rear light.





78


Brake Light
Wire Connect



Bring the Red Wiring, Brake wiring (RD) of the Harness Central Lock No.40 connecting with the wiring (Green/White wire) of the vehicle.

79


Dim Light
Wire Connect



Bring the blue wiring, Dimlight of the Harness Central Lock No.40 connecting with Dimlight of the vehicle (green wiring).

80


Turn Light
Wire Connect



Bring the yellow Wiring, Turn light wiring (YL) of the Harness Central Lock No.40 connecting with the Green/Yellow wiring (GR/YL) Turn Light wiring of vehicle.

81


Ground
Wire Connect



Bring the Black Wiring, GROUND of the Harness Central Lock No.40 connecting with the White/Black (WH/BK) Ground wiring of the vehicle rear light.




82




Tight up all the wiring by using the Cable Tie

83




Reassemble the vehicle rear light.

84



85



Tight up the wiring at the driver side by using the Cable Tie, then close the vehicle cover.




86

Check the Central Lock / Room Lamp working.



Central Lock checking by pressing the vehicle remote key at the Lock position,
Canopy will be lock and cannot open.


87



Central Lock checking by pressing the vehicle remote key at the Unlock position, Canopy will be open.



88



Room Lamp checking by opening the rear door then
the Room Lamp will be on.




SAMMITR

Opening Function of all canopy model





SAMMITR

Front Window function usages will be the same for all model, V2, V4 and TL1.




Use the key is unlock function will be the same for all model, V2, V4 and TL1.


Open the backdoor function are different.




User manual



Slide Window (Left-Right)




Squeeze the lock side to open.




The Picture shows how to open the side window.




User manual



Glass Birdwing Window Left-Right
(Handle Lock)




Turn around the canopy lock as shown in picture to
open the side window.




Picture shows how to open the side window.


User manual



Glass Birdwing Window Left-Right
(Handle Lock)




Turn around the canopy lock as shown in picture to
close the side window.





Picture shows how to close the side window.




User manual



Solid Birdwing Window Left-Right
(Handle Lock)




Turn around the canopy lock as shown in picture to open the side window.





Picture shows how to open the side window.


User manual



Solid Birdwing Window Left-Right
(Handle Lock)




Turn around the canopy lock as shown in picture to close the side window.



Picture shows how to close the side window.




User manual




Backdoor


User manual




Slide Window (Left-Right)




Use the handle as shown in picture to open the backdoor.



Squeeze the lock side to open.




The Picture shows how to open the backdoor.



The Picture shows how to open the side window.




User manual




Glass Birdwing Window Left-Right
(Handle Lock)


User manual




Glass Birdwing Window Left-Right
(Handle Lock)




Turn around the canopy lock as shown in picture to open the side window.



Turn around the canopy lock as shown in picture to close the side window.




Picture shows how to open the side window.



Picture shows how to close the side window.




User manual




Backdoor


User manual




Slide Window (Left-Right)




Pull the stick of handle to open the back door.



Push the button in side canopy and slide back to open.




The Picture shows how to open the backdoor.




Picture shows how to open the side window from inside.




User manual



Glass Birdwing Window Left-Right
(Handle Lock)




Turn around the canopy lock as shown in picture to
open the side window.




Picture shows how to open the side window.


User manual



Glass Birdwing Window Left-Right
(Handle Lock)




Turn around the canopy lock as shown in picture to
close the side window.




Picture shows how to close the side window.




User manual



Backdoor



Push the button to open the back door.



The Picture shows how to open the backdoor.