




Mechanical Installation Manual J-Deck Models

Steel Canopy : S-Plus V2
Version 1.0



Part In Main Carton

P1: Steel Canopy S-Plus V2




Kit Box

Part List Paper




K1 : Roofrack R/L



K2 : Rubber R/L



K3 : Switch Case



K4 : Wiring No.38




K7 : T Paint


Require Tools



T1 : 13 mm. Wrench




T3 : 10,12mm. Torque Wrench



T4 : Measuring Tape/Ruler/Pencil




T2 : 10 mm. Wrench



T5 : Tape



T6 : Electric Tape



T7 : Fabric




Mechanical Installation Manual J-Deck Models


Steel Canopy : S-Plus V2
Version 1.0

Part List


Bracket



A : 4 pieces



B : 4 pieces



C : 4 pieces

No. 12 mm.



D : 12 pieces



E : 12 pieces

No. 8 mm.



F : 12 pieces




G : 8 pieces


Rubber (EPDM)

Require Tools


T1 : 10 mm. Impact Drill



T2 : 12 mm. Torque




T3 : No.5 Hex Screwdriver





1

The Procedure of checking the Sammitr canopy box before installation.




Brand
Model
Type
Year
Color
Part number
Serial number

1. Make sure that Sammitr canopy box is in good condition, No marks, distorts or any damages.

2. Check Model / Year of the canopy and Model / Year of the vehicle which have to be matching.

3. Check canopy serial number / model code and vehicle serial number / model code which have to be matching by looking at the rear canopy handle.

4. Check all the accessories received inside the box with the Packing List.



Packing List




2

The preparation process of Sammitr Canopy


S-Plus V2 model before installation with the vehicle.

1




1. Canopy have to be in good condition, no damage, dent, cracks, smooth surface including no window damages or cracks.
2. Locking system is working for both keys.
3. Canopy sides are not damage, dent or cracks.
4. Canopy front window panel is working (open/close), no cracks or damages occurrences.
5. Check the Rear Door by open and close.


2




4



3




5






3

The process of Roof rack installation manual of the S-Plus V2 canopy before installs on the vehicle.



Roof rack Front Part – Rear Left






11

The process of checking and preparing the Toyota Hilux REVO J-DECK vehicle before install the canopy.

1. Clean up the vehicle body including the top, all sides and Rear tub.
2. Cover the fabric to protect the scratches resistant.








SAMMITR

12

T3



13






Rear

Back



SAMMITR






17

Installation Steel Canopy S-PlusV2 and Frame Weather Strip on cabin.


Steel Canopy S-Plus V2






SAMMITR

18





19







20



Torque Wrench Tightening To 18-20 Nm



Torque Wrench Tightening To 14-16 Nm

Note: Over tightening could lead to stressing of structure, leading to potential damage to the canopy. Do not over tighten.